110*55mm

XMax®

XMax® II Pro

Anleitung

21+

Achtung!

Bitte sorgen Sie dafür, dass das Gerät nicht für längere Zeit einen niedrigenLadestand hat, denn wenn der Ladestand unter 2% fällt, lässt es sich nicht mehr aufladen.

Laden Sie den Akku mit einem dafür vorgesehenem Ladegerät vonguter Qualität und niemals mit mehr als 5V/1A. Andernfalls kanndies die Batterie beschädigen und zu schweren Verletzungen,sowieBränden führen.

SICHERHEIT

Das Gerät dient der Aromatherapie und sollte für trockene Kräuter verwendet werden. Dieses Gerät ist nicht für den Einsatz von illegalen Substanzen bestimmt und darf nur von Erwachsenen über 18 Jahren verwendet werden. Von Kindern fernhalten. Jeder andere Gebrauch ist unzulässig. Der Importeur übernimmt für Schäden, die durch ungeeigneten, falschen oder unvernünftigen Gebrauch hervorgerufen worden sind, keinerlei Verantwortung. Benutzen Sie elektronische Geräte niemals in der Nähe von Wasser. Belüftungsöffnungen niemals blockieren oder abdecken. Benutzen Sie nur Zubehör, welches auch vom Hersteller dafür freigegeben ist. Wartung und Reparatur sollte nur von qualifiziertem Fachpersonal durchgeführt werden. Um einen Stromschlag zu vermeiden, öffnen Sie das Gerät bitte nicht selbst. Aus Sicherheitsgründen ist es nur erlaubt das Gerät von qualifiziertem Fachpersonal öffnen zu lassen. Solange das Gerät in Betrieb ist, lassen Sie es nicht unbeaufsichtigt.

XMax® II Pro ÜBERBLICK

TECHNISCHE DETAILS

Kapazität	18650 3.7V 2600mAh
Batteriespannung	3.5V- 4.2V
Ladegerät/Ausgabespannung	5.0V/ 500mAh
Ein-/Ausschalten	Den Schalter 3 mal hintereinander drücken
Dauer Sicherheitsleistung	5 Minuten
Batterie schwach	LED Anzeige blinkt 10 Mal schnell
Material:	Rostfreier Stahl
Heizkammer:	Keramik mit eingebettetem Heizelement

BEDIENUNGSANLEITUNG

1. Entfernen Sie das Mundstück aus Gummi, sodass die Heizkammer freigelegt wird.
2. Füllen Sie die Kammer vorsichtig mit Kräutern. Pressen Sie die Kräuter nicht zu stark zusammen, damit der Luftstrom nicht unnötig verringert wird. Schließen Sie dann das Mundstück wieder an. Wenn Sie Flüssigkeiten verwenden, füllen Sie ein wenig Flüssigkeit in die Füllkammer Vergewissern Sie sich, dass die Füllkammer teilweise gefüllt ist.
3. Drücken Sie den Ein/Aus Schalter 3 mal schnell hintereinander. Das rote, grüne und weiße Licht wird aufleuchten, dann wird der Batteriestand angezeigt.
4. Warten Sie bis die Batterieanzeige ausgeht, drücken Sie dann den Knopf 2 Sekunden lang um die Temperatur einzustellen. Wenn Sie den Knopf länger als 4 Sekunden gedrückt halten, wird das Gerät durch verschiedene Temperatureinstellungen springen
5. Nachdem Sie die Temperatur ausgewählt haben, heizt sich das Gerät automatisch auf.

6. Das LED Licht blinkt während des Erhitzens und leuchtet durchgängig sobald die gewählte Temperatur erreicht ist. Dann schaltet es sich automatisch aus. Atmen Sie langsam und tief durch das Mundstück ein während das Licht an ist.

Temperatur Einstellung Licht	Anzeige Batteriestand
● ROT: 180°C/356°F ● BLAU: 190°C/374°F ● GRÜN: 200°C/392°F ● LILA: 210°C/410°F ○ WEIß: 220°C/428°F	● ROT: UNDER 20% ● GRÜN: UNDER 60% ○ WEIß: 60-100%

Geringe Ladung: Das rote Licht blinkt 10 mal, dann schaltet sich das Gerät automatisch aus.

AUFLADEN

TUm die Batterie zu schützen, wird empfohlen, den XMax® II Pro vor dem ersten Gebrauch mindestens 6 Stunden aufzuladen. Er kann auch über USB geladen werden, das dauert allerdings länger.

Beim Aufladen leuchten nacheinander die roten, grünen und weißen Lichter, um den Batteriestand anzuzeigen. Die Lichter schalten sich aus wenn das Gerät vollständig geladen ist.

Lassen Sie den XMax® II Pro und das Ladegerät nach Benutzung auskühlen. Lagern Sie

das Gerät an einem kühlen und trockenem Ort.

ENTSORGUNG

Im Sinne des Umweltschutzes darf dieses Gerät am Ende seiner Lebensdauer nicht mit dem Hausmüll entsorgt werden. Die Entsorgung kann über den Take-away Kundendienst oder lokal verfügbare Rückgabe-und Sammelsysteme erfolgen. Die WEEE Richtlinie dient der Reduktion der zunehmenden Menge an Elektronikschrott aus nicht mehr benutzten Elektro- und Elektronikgeräten.

GEWÄHRLEISTUNG

Für dieses Gerät gelten 2 Jahre Gewährleistung ab dem Kaufdatum. Als Nachweis für das Kaufdatum gilt die vom Händler ausgestellte Rechnung, auf dem der Name des Gerätes und das Kaufdatum angegeben sein müssen.

© Topgreen Technology 2016

WARNUNG

1. KEINE beschädigten Batterien in unseren Vaporizern benutzen
2. Bitte benutzen Sie ausschließlich Originalakkus oder Akkus von hoher Qualität
3. Benutzen Sie immer nur für Ihr Gerät passende Akkus und tragen Sie diese niemals lose in Ihrer Tasche mit andersen metallischen Gegenständen.

WARNUNG

Bitte füllen Sie KEINE Flüssigkeiten in die Kammern unserer Vaporizer

Caution

Please do not put this product away or leave it for extended periods of time with low charge because if the battery falls below 2% then it will no longer accept a charge.

Charge the battery with a good quality & dedicated charger,Never more than 5V/1A.Otherwise,it will cause damage to battery,serious personal injury,fire.

Thanks for purchasing the XMax® II Pro diffuser pen. To ensure best experience, please read and understand the instructions fully before your first use of the XMax® II Pro diffuser pen. We strongly recommend these instructions are kept for future reference.

We hope you enjoy the quality and performance of your new diffuser pen.

You must be of legal age in your jurisdiction to purchase or use the XMax® II Pro diffuser pen. This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor.

Note that the XMax® II Pro diffuser pen is not a medical device and is not intended to diagnose, cure, treat or prevent any diseases or other conditions.

XMax® II Pro diffuser pen is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties and/or imprisonment under the law of your jurisdiction.

THIS PRODUCT DOES NOT CONTAIN HERBS .

XMax® II Pro OVERVIEW/CONTENTS

SPECIFICATIONS

Capacity	18650 3.7V 2600mAh
Battery Voltage	3.5V- 4.2V
Charger/Output Voltage	5.0V/ 500mAh
On/Off	Click the button 3 times consecutively
Safety Power Duration	5 minutes
Battery Low	LED lights flash 10 times rapidly
Cup Material:	Stainless steel
Heating Chamber:	Ceramic with embedded heating element

OPERATION GUIDANCE

1.Remove XMax® II Pro's rubber mouthpiece, exposing the heating chamber.
2. Always fil the chamber with moderate spices, etc. Do not compress the plant material too much so that the airflow is not unnecessarily impeded. Then put back the mouthpiece. OR- if using with fluid, place a small amount of fluid into the ss cup, make sure the filling chamber is partially filled.
3. Click the button 3 times in quick succession. The Red, Green and White lights will flash, and then the battery level light will be displayed. (White light=Full Power, Green light=Med Power, Red light=Low Power)
4. Wait for the battery level indicator light to go out, then hold the button 2 seconds to select temperature, if hold more than 4 seconds it will cycle through temperatures at a faster rate.
5. The device will automatically heat up after temperature is selected.

6.The LED light will flash while heating up, and will be stable when reaching the selected temperature until it auto shuts off. Inhale slowly and deeply from the mouthpiece while the light is on.

Temperature Settings Light	Battery Level Display
● RED: 180°C/356°F ● BLUE: 190°C/374°F ● GREEN: 200°C/392°F ● PURPLE: 210°C/410°F ○ WHITE: 220°C/428°F	● RED: UNDER 20% ● GREEN: UNDER 60% ○ WHITE: 60-100%

Low Power: The red light will flash 10 times and the device will automatically shut off.

CHARGING

To protect and extend the battery, we recommend charging your XMax® II Pro via Wall Adapter for at least 6 hours before the first use. It can also be charged via USB port but takes longer time. (External 18650 battery charger is available but not included.)

When charging, XMax® II Pro's LED lights will cycle through red, green and white to indicate the battery level. The lights will go out when fully charged.

If you have any concerns, or if there are any problems please switch off the XMax® II Pro and pull the power adapter cord immediately. Do not try to remedy the defect yourself. Contact our Customer Service directly(support@topgreencig.com).

After using the XMax® II Pro and power adapter, allow them to cool down before placing them in storage. Please store them in a dry place protected against the effects of weather and out of the reach of children or unqualified persons.

Please use original charger rather than other manufacture chargers. XMax® II Pro cannot be used while charging. Otherwise it will be dangerous.

WARRANTY

To claim under the warranty please contact your seller.

We warrant solely to the original purchaser of the XMax® II Pro that within the warranty period(as defined below), the XMax® II Pro will be free from defects in materials and workmanship under normal use, and will conform to Company's published specifications of the Products. The foregoing warranty is subject to the proper storage, transportation and use of the Products, but does not include defects in batteries, buttons and similar parts subject to wear and tear or deterioration and other special, consequential or incidental damages. Customer agrees to accept responsibility for such risks and to not hold the manufacturers, distributors or retailers (including owners and employees) responsible for any incident, injury to persons, or damage to property.

Upon delivery, Customer should inspect the Products immediately for conformity and

visible defects. If there is a quality problem, Customer shall give Company written notice of any non-conformities or visible defects regarding the Products and contact Company in writing concerning return or repair. Our team shall provide timely service within 24 hours after receiving Customer's written notice. Customer must provide photos/video or other evidence as a proof within 7 days.

The warranty period for XMax® II Pro diffuser pen begins on the date when the Product is purchased by the Customer, and is valid for six months.

Warranty options at the Company's description:
1.Repair the product defect
2.Exchange the product with a new or functionally equivalent product
3.The limited warranty does not apply to normal performance degradation of batteries or neglect and non-adherence to cleaning instructions.

All requests and notices from all Customers under this warranty shall be emailed to support@topgreencig.com

© Topgreen Technology 2016

WARNING

1.Do NOT use damaged batteries in all our vaporizers
2.Please use our original batteries or high quality batteries from authentic brands instead of clones
3.Always use battery suitable for your device. Never carry it loose in your pocket with other metal objects.

WARNING

Please do NOT load any liquids into the chamber of all of our vaporizers